

These instructions are provided for your safety.

Please read them carefully before commencing work and retain them for future reference.


### **SAFETY INFORMATION**

- \* If you are in any doubt consult a person competent to give advice on the installation of electrical equipment.
- \* Before installation and servicing disconnect the electricity supply at the fuse board.
- \* To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
- \* This fitting should be fitted to a lighting supply (with earth) protected by a 5 amp fuse or equivalent circuit breaker.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Dispose of old bulbs carefully.

### **INSTALLATION**

**Note: This fitting has a 3 year guarantee against corrosion. This fitting should only be installed in normal non aggressive atmospheric locations to prevent corrosion. Aggressive environments to be avoided include locations by the sea, polluted atmospheres or near heating flue outlets.**

1. Ensure the house electricity supply is off at the fuse board.
2. If removing an existing fitting, first note down all wiring connections.
3. Unscrew screws at top and bottom of wall light. Save small round rubber washers carefully for replacement later, as they form a seal around the screws and prevent rusting.
4. Unscrew and remove cup at bottom of lampholder.



5. Thread house supply wire through hole in bottom of backplate. Fix backplate firmly to wall through fixing holes.
7. Make all electrical connections through the connector block.  
Connect the live (brown) wire of the wall light to the supply live wire.  
Connect the neutral (blue) wire of the wall light to the supply neutral wire.
8. Ensure electrical connections are tight and no loose strands of wire are left out of the connector block. Cover the connectors and adjacent wiring with a good quality insulation tape. **Be careful not to damage wiring.**
9. Replace cup at bottom of lampholder.
10. Fit the bulb, type and wattage as indicated on the fitting. **The wattage indicated must not be exceeded.**
11. Replace front of wall light using screws and washers removed at 3. above.
12. Switch on the electricity supply at the fuse board.

**GENERAL INFORMATION**

This fitting is designed for external use, it must be fitted to a DRY FINISH as any dampness in concrete, wood stain, paint and etc can damage finish. **Do not use polish or abrasive cleaner - just a soft slightly damp cloth.**

*To register your product for an extended five-year warranty, please complete the simple form at*

[www.darlighting.co.uk/warranty](http://www.darlighting.co.uk/warranty)

*You'll need to fill in the details of the product, the retailer you purchased it from, and also the installer and the installation. Please also upload a clear copy of the original purchase invoice or receipt to complete this registration.*

**UK:** *där Lighting Ltd, Wildmere Road, Banbury, Oxon, OX16 3JZ*

**Ireland & EU:** *Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18*