



WOOD FLOOR LAMP ASSEMBLY INSTRUCTIONS


These instructions are provided for your safety. Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

- * The supply cable runs through the inside of the fitting, take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- * If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- * Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Dispose of old bulbs carefully.
- * If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- * When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

FLOOR LAMP ASSEMBLY

- 1. Unpack the floor lamp and remove all packaging. Be careful that you do not scratch surface of the stems whilst removing plastic wrapping.
- 2. Cover floor with a soft cloth to avoid damage to the flooring and surface of the product then lay this product out on the floor. Assembly should take place with the product lying flat.
- 3. Where required remove the plastic cable protectors which are fitted at cable entry points into stem and floor lamp base.
- 4. Hold the stem with lamp holder firmly and ensure central ring is correctly seated then screw stems together, taking care to hold stem parallel so that they do not cross thread. \bigcirc
- 5. Gently <u>pull</u> the excess cable out of base until the lower stem meets the centre of base.
- 6. Hold assembled stems firmly and screw base onto assembled stems, make sure you do not cross the treads, if in doubt unscrew then start again. ② Take care not to over tighten.
- 7. With product laid on a covered floor fit and tighten the cable restraint supplied to secure cable in place. 3 Note: do not leave excess slack in the base.
- 8. Remove shade ring from lamp holder, fit shade and secure in place with shade ring. 4 + 5
- 9. **Fit bulb**, type and wattage as indicated on fitting. **The wattage indicated must not be exceeded.**
- 10. Your floor lamp is now ready for use.





GENERAL INFORMATION

This product is designed for internal use only. Do not use polish or abrasive cleaner – just a soft dry cloth.

To register your product for an extended five-year warranty, please complete the simple form at

www.darlighting.co.uk/warranty

You'll need to fill in the details of the product, the retailer you purchased it from, and also the installer and the installation. Please also upload a clear copy of the original purchase invoice or receipt to complete this registration.

UK: där Lighting Ltd, Wildmere Road, Banbury, Oxon, OX16 3JZ **Ireland & EU**: Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18