

ENID CHANDELIER FITTING INSTALLATION INSTRUCTIONS

These instructions are provided for your safety.

Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

- * If you are in any doubt consult a person competent to give advice on the installation of electrical equipment.
- * This fitting should be fitted in accordance with IEE Wiring Regulations and the Building Regulations.
- * To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electricity supply without your knowledge.
- * To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
- * This fitting is Class I = $\frac{1}{\text{I}}$ and should be fitted to a lighting supply (with earth) protected by a 5 amp fuse or equivalent circuit breaker.
- * Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- * When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

INSTALLATION

1. Ensure the house electricity supply is off at the fuse board
2. Before removing the existing fitting, carefully note the position of each set of cables. If there are loop in cables that are not connected to the light these must be terminated in a separate terminal block not connected to the fitting.
3. Remove mounting bracket from fitting by removing the two screws located on either side of the ceiling cup. Using the bracket as a template, mark and then drill the fixing holes in the ceiling. Ensure that the holes are drilled into a joist or other suitable mounting and not just the plaster
4. Carefully screw the main stem of the chandelier into the bottom section as shown in figure ① of the diagram below, taking care not to cross thread. Secure stem in place by tightening the grub screw located at the base of the stem using the hex key provided.
5. Chain links may be adjusted to reduce the height of the fitting. Using two pairs of pliers carefully open the chain links and remove the required number of links. Close the links. Note: Cloth should be used between the jaws of the pliers to protect the decorative finish. Pull any excess cable through the ceiling cup;
IMPORTANT ensure the chain is supporting the weight of the fitting and not the electrical cable.
6. Attach the bottom chain link to the top hanging ring of the chandelier. The link is opened by twisting the barrel nut at the side anti-clockwise, hooking the chain link over the top ring of the chandelier and retightening.
7. Carefully remove the protective packaging surrounding the crystal dropper swags attached to the top of the chandelier frame. Attach the hooks at the end of the swags to the adjacent holes in the chandelier frame as shown in illustration ② below.
8. Fix the mounting bracket to ceiling using suitable fixings. **Take care not to damage wiring.**
9. **The weight of the fitting must be supported whilst making the electrical connections as follows:**
 - Connect supply live (normally brown or red) to fitting live (marked "L") on the terminal block.
 - Connect supply neutral (normally blue or black) to fitting neutral (marked "N") on the terminal block.
 - Connect supply earth (normally green/yellow or unsheathed) to earth (marked " $\frac{1}{\text{I}}$ ") on terminal block.

NOTE: Ensure electrical connections are tight and no loose strands of wire are left out of the terminal block.
10. Attach the fitting to the mounting bracket using the retaining screws removed earlier. **Take care not to trap wires in the process.**
11. Fit the bulb: Type and wattage as indicated on the fitting. **The wattage indicated must not be exceeded.**
12. Switch on the electricity supply at the fuse board.

GENERAL INFORMATION

This fitting is designed for internal use only and must be fitted to a DRY SURFACE as any dampness in plaster or paint can damage the finish. **Do not use polish or abrasive cleaner - just a soft dry cloth.**

LAURA ASHLEY

IL3576

