

## FLOOR LAMP

### ASSEMBLY INSTRUCTIONS

**These instructions are provided for your safety.**


Please read them carefully before commencing work and retain them for future reference.

### SAFETY INFORMATION

- \* Supply cable runs through the inside of this product, take care not to place undue stress on cable whilst unpacking to prevent the possibility of a poor connection.
- \* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Dispose of old bulbs carefully.
- \* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- \* When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

### ASSEMBLY

1. Unpack the floor lamp and remove all packaging. Be careful that you do not scratch the surface of the poles whilst removing the plastic wrapping. Also ensure base does not get scratched by the ends of the poles or the plug.
2. Remove any packaging material located along the cable way before attempting to assemble this product.
3. Lay the product out on the floor, which has been previously covered with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.
4. Hold the stem with lamp head firmly then screw top pole into the lamp head stem, taking care to hold poles parallel so that they do not cross thread. ①
5. Screw lower stem to the middle stem, taking care to hold poles parallel so that they do not cross thread. ②
6. Gently pull the excess cable out of base until the lower pole meets the base hole.
7. Fit the assembled stem into the base support ③ and at the same time gently pull excess cable out of the base then tighten 2 x hex screws located at the base to fully secure the stem. ④ **Ensure the shade is directly above the floor lamp base to maintain stability.**
8. **Fit bulb**, type and wattage as indicated on fitting. ⑤ **The wattage indicated must not be exceeded.**



### GENERAL INFORMATION

This floor lamp is designed for internal use only. Do not use polish or abrasive cleaner – just a soft dry cloth.

*To register your product for an extended five-year warranty, please complete the simple form at*

[www.darlighting.co.uk/warranty](http://www.darlighting.co.uk/warranty)

*You'll need to fill in the details of the product, the retailer you purchased it from, and also the installer and the installation. Please also upload a clear copy of the original purchase invoice or receipt to complete this registration.*

**UK:** *där Lighting Ltd, Wildmere Road, Banbury, Oxon, OX16 3JZ*

**Ireland & EU:** *Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18*