

# LAURA ASHLEY

IL4537

## BURDALE FLOOR LAMP ASSEMBLY INSTRUCTIONS


These instructions are provided for your safety.  
Please read carefully before commencing work and retain for future reference.

### SAFETY INFORMATION

- \* The supply cable runs through the inside of this product. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- \* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Do not exceed wattage stated.
- \* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- \* To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instructions before assembly.
- \* When changing the bulb, always unplug from the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- \* **If moving the floor lamp always carry it from the base. Do not lift the floor lamp by the stem only as damage may occur**
- \* Place this product out of direct sunlight.

### ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat. It may be necessary to remove protective packaging (plastic / cardboard) located at cable.
3. Attach the metal all-thread to the underside of the lamp stem by rotating into place until tight ①
4. Pass the all-thread protruding from the lamp stem through the base section ②
5. Place the serrated washer over the all-thread on the underside of the base and attach the fixing nut. Tighten the parts with the spanner tool provided until secured ③
6. Fit the felt base pad to the underside of the lamp base ④
7. Adjust the rise and fall mechanism screws to the desired height ⑤⑥
8. Stand the floor lamp upright and ensure all the assembled parts are fully tightened.
9. Fit bulb: type and wattage as indicated on fitting. **The wattage indicated must not be exceeded**
10. Floor lamp is now ready for use.



### GENERAL INFORMATION

This fitting is designed for internal use only. **Do not use polish or abrasive cleaner - just a soft dry cloth.**