

GLASS FLOOR LAMP


These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

- * If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instruction before assembly.
- * This floor lamp is fitted with a 3 Amp fuse and is suitable for 240 Volt ring mains.
- * Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- * When changing the bulb, ensure product is unplugged and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Lay the product out on the floor. If the floor is not carpeted, please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.
3. It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.
4. Screw lower stem onto bulb holder stem, take care to hold stems parallel to avoid cross threading. ①
5. Screw middle stem onto assembled stems, take care to hold stems parallel to avoid cross threading. ②
6. Screw lower stem onto assembled stems, take care to hold stems parallel to avoid cross threading. ③
7. Offer assembled stems onto the base ④ and gently pull excess cable out of the base until the stem meets the base support post.
8. Make sure assembled sections are fully tightened, then align lamp holder to front centre of the base then use hex key to tighten hex screws onto position. ⑤
9. Peel off protective film from base felt then attach felt underside of base whilst making sure it is centred. ⑥ Remove the shade ring from the lampholder, fit glass shade ⑦ and then secure into position using the shade ring. ⑧
10. Fit bulb, type and wattage as indicated in the floor lamp. ⑨ **The wattage indicated must not be exceeded.**
11. Floor lamp is now ready for use.



GENERAL INFORMATION

This floor lamp is designed for internal use only.

Do not use polish or an abrasive cleaner - just a soft dry cloth.

To register a product for an extended five-year warranty, please complete the simple form at <https://www.darlighting.co.uk/blog/warranty-registration/> with the retailer, product and installers and installation details and upload a clear copy of the original purchase invoice/receipt.

UK: Dar lighting ltd, Wildmere Road, Banbury, Oxon, OX16 3JZ

IRELAND & EU: Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18