

## TATE FLOOR LAMP ASSEMBLY INSTRUCTIONS


These instructions are provided for your safety.  
Please read carefully before commencing work and retain for future reference.

### SAFETY INFORMATION

- \* The supply cable runs through the inside of this product. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- \* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Do not exceed wattage stated.
- \* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- \* To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instructions before assembly.
- \* When changing the bulb, always unplug from the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- \* **If moving the floor lamp always carry it from the base. Do not lift the floor lamp by the stem only as damage may occur.**

### ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove the packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat. It may be necessary to remove protective packaging (plastic/ cardboard) located at cable.
3. Screw the upper pole onto the lamp holder section, taking care to hold the poles parallel to avoid cross threading. Hold the lamp holder section still and only turn the upper pole so as not to twist the cable. If cross threading occurs undo and start again ①
4. Screw the centre pole onto the upper pole. Hold the upper pole still and rotate only the centre pole to prevent the cable twisting ②
5. Screw the next pole onto the centre pole. Hold the centre pole still and rotate only the lower pole to prevent the cable twisting ③
6. Screw the final pole onto the assembly. Hold the upper assembly still and rotate only the lower pole to prevent the cable twisting ④
7. Rotate the base onto the pole assembly. Keep poles parallel to avoid cross threading. Keep the pole assembly stationary and only rotate the base section ⑤
8. Gently pull any excess cable through the hole in the base ⑥
9. Loosen the saddle clamp cable restraint located in the base section with a suitably sized screwdriver. Pass the electrical cable under the clamp, push the securing bar down and retighten the screw ⑦
10. Attach the protective foam base pad evenly to the base of the floor lamp where applicable.
11. Stand the floor lamp upright and ensure all the assembled parts are fully tightened.
12. Fit bulb: type and wattage as indicated on fitting. **The wattage indicated must not be exceeded.**
13. Floor lamp is now ready for use.



### GENERAL INFORMATION

This product is designed for internal use only. **Do not use polish or abrasive cleaner – just a soft dry cloth.**