


GLASS TOUCH SHADE TABLE LAMP

SAFETY INFORMATION

- * If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instruction before assembly.
- * When changing the bulb, ensure product is unplugged and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Where required, remove packaging material / shade ring or spacer from lamp holder.
3. (Where supplied fit, rubber washer) Fit the glass onto the base.
4. Where supplied, fit rubber washer then fit large washer over the lamp holder and secure these into position by rotating the spacer clockwise. Take care not to over-tighten.
5. Fit bulb: type and wattage as indicated on fitting. **The wattage indicated must not be exceeded.**
6. Your table lamp is now ready for use. Operate the lamp by touching the table lamp base. **ON – OFF.**



GLASS TOUCH TABLE LAMP

SAFETY INFORMATION

- * If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instruction before assembly.
- * When changing the bulb, ensure product is unplugged and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Where required, remove packaging material / shade ring or spacer from lamp holder.
3. (Where supplied fit, rubber washer) Fit the glass onto the base.
4. Where supplied, fit rubber washer then fit large washer over the lamp holder and secure these into position by rotating the spacer clockwise. Take care not to over-tighten.
5. Fit bulb: type and wattage as indicated on fitting. **The wattage indicated must not be exceeded.**
6. Your table lamp is now ready for use. Operate the lamp by touching the table lamp base. **ON – OFF.**

